

INSTRUCTIONS FOR USE



NB: After any adjustment, always push the crown back in to the normal position (I) in order to keep your watch water-resistant.

ADJUSTMENT OF THE TIME



1. Pull out the crown to position (III). The second hand will stop.
2. Adjust the time by turning the crown in the desired direction.
3. Push the crown back in to position (I). The second hand will start moving again.

NB: At each changeover at midnight (24 hours), the date and moon phase advance one position.

RAPID ADJUSTMENT OF THE DATE



1. Pull out the crown to position (II).
2. Adjust the date by turning the crown clockwise.
3. Push the crown back in to position (I).

RAPID ADJUSTMENT THE MOON PHASE



NB: For perfect synchronization, adjustment of the moon phase must be done after having made all the other adjustments described above.

1. Pull out the crown to position (II).
2. Adjust the moon phase by turning the crown counterclockwise.
3. Push the crown back in to position (I).

RAYMOND WEIL S.A.

Avenue Eugène-Lance 36-38
P.O. Box 1569
1211 Geneva 26
Switzerland
Tel +41 (0) 22 884 00 55
Fax +41 (0) 22 884 00 50



GENERAL INFORMATION

info@raymond-weil.ch

AFTER SALES SERVICE

customer-service@raymond-weil.ch

WEBSITE

raymondweil.com

RAYMOND WEIL


GENEVE

INSTRUCTIONS FOR USE

SELF-WINDING MECHANICAL WATCH
WITH DATE AND MOON PHASE

ZGU 755

Printed on 17/10/2019 at 23:02 by alexa.o



INTRODUCTION

Congratulations on your choice of a watch from the prestigious RAYMOND WEIL collection, a dynamic expression of masterful design and the constant objective of supreme quality that have been the hallmarks of the brand since its creation.

Your RAYMOND WEIL watch was hand-assembled by our master watchmakers according to the most rigorous quality standards of the Swiss watch industry.


In order to guarantee that your RAYMOND WEIL watch will function perfectly for many years to come, please pay close attention to the advice contained in these instructions for use as well as in the international guarantee.

Your watch has a self-winding mechanical movement with an exclusive complication module, and it has a running reserve of 38 hours.



NB: if your watch has stopped, before any adjustment it is necessary to wind it manually by turning the crown clockwise 20-30 times in position (I). When you wear the watch, it will wind automatically with the natural movements of your wrist.

SELF-WINDING MECHANICAL WATCH WITH DATE AND MOON PHASE



- ① Hour hand
- ② Minute hand
- ③ Second hand
- ④ Date
- ⑤ Moon phase indicator

- A Crown
- I Normal or winding position
- II Adjustment of the date and moon phase
- III Adjustment of the time and stop seconds